

*These commands are standard FS2002 commands
and are not special to LAGO Twin Otter*

QUICK KEYS FOR PANELS

[SHFT]-[1]	MAIN PANEL
[SHFT]-[2]	YOKE + THROTTLE
[SHFT]-[3]	OVERHEAD
[SHFT]-[4]	ENGINES
[SHFT]-[5]	WARNING LIGHTS
[SHFT]-[6]	PRIMARY
[SHFT]-[7]	FUEL SWITCHES
[SHFT]-[8]	RADIOS/NAV
[SHFT]-[9]	AUTOPILOT

VIRTUAL COCKPIT KEYS

[CTRL]-[ENT]	MOVE HEAD BACK
[CTRL]-[BCKSPC]	MOVE HEAD FORWARD
[SHFT]-[ENT]	MOVE HEAD UP
[SHFT]-[BCKSPC]	MOVE HEAD DOWN
[CTRL]-[SHFT]-[BCKSPC]	MOVE HEAD LEFT
[CTRL]-[SHFT]-[ENT]	MOVE HEAD RIGHT
[SPACE]	RESET HEAD ☺
[SHFT]-[=]	ZOOM IN
[SHFT]-[-]	ZOOM OUT
[BCKSPC]	RESET ZOOM

USE HATSWITCH ON STICK TO PAN VIEW.

DOOR KEYS

[SHFT]-[E]-[1]	OPEN COCKPIT
[SHFT]-[E]-[2]	OPEN FREIGHT

LAGO TWIN OTTER

CHECKLISTS & KEY COMMANDS

Copyright © Suprunov & LAGO 2002

LAGO

WWW.LAGOONLINE.COM

Via Adua, 22
21045 Gazzada
Schianno (VA)
Italy

*This checklist is designed to be
printed double sided and folded
into a small leaflet.*

Cockpit Preparation

PARKING BRAKE SET
BATTERY..... ON
DC MASTER..... ON
RADIO POWER..... ON
SEATS/ SEAT BELTS OK
PAPERS / DOCUMENTS OK
RADIOS..... SET
AUTOPILOT SET
GENERATOR SWITCHES OFF
ALTIIMETER SET

Startup

BEACON ON
PARKING BRAKE SET
AREA..... CLEAR
PARKING BRAKE ON
PROPELLER FULL
MIXTURE RICH

IGNITION BOTH
STARTER LEFT
MANUAL IGNITION START
MONITOR ENGINE OK
GENERATOR LEFT ON
MANUAL IGNITION OFF
REPEAT RIGHT ENIGINE..... OK

IGNOTION L or R
STROBE..... ON
TAXILIGHT ON
DE ICE (when needed)..... ON

Taxi

TRIM 0%
DOORS..... CLOSED

Warm Up

RPM 1200
TEMPERATURE 100°F
RPM 1800
TEMPERATURE <200°F..... OK

Take-Off

IGNITION BOTH
LANDING LIGHTS ON
PROP DEICE OFF
FLAPS 10
BRAKES SET
PROPELLOR FULL

POWER 100%
ROTATE 90 KT
INITIAL CLIMB 110 KT
FLAPS 0
TRIM SET

Climb

LANDING LIGHTS OFF
TORQUE..... 80%
PROPELLOR 1900
IGNITION 1 or 2
LANDING LIGHTS OFF
TRIM SET
IGNITION 1 or 2

Cruise

ALTIMETERS STAND
PROPELLOR SET
TORQUE..... SET
NO SMOKING/ SEATBELTS..... SET

Before Landing

FUEL..... BOTH
CABIN INFORMED..... OK
SEATBELTS / NO SMOKING SET
TRIM..... SET
CREW BRIEVING..... OK
LANDING DATA SET
LIGHTS ALL ON
ALTIMETER LOCAL
MISSED APP ALT SET
IGNITION BOTH
FLAPS SET
PROPELLOR FULL

After Landing

IGNITION 1 or 2
FLAPS UP
LANDING LIGHT OFF

After Parking

PARKING BRAKES SET
PROP FULL
MIXTURE CUT OFF
GENERATORS..... OFF
LIGHTS OFF
BUS DC..... OFF
DC MASTER OFF
BATTERY OFF
APOLOGIZE TO PASSENGERS DONE