



You can use this simple LED circuit to indicate RF current in your BITX20 feedline. All it takes is a small toroid core, some wire, and an LED. This does not show forward versus reflected current, just that there is current present.